

ADDITIONAL INSTRUCTIONS FOR UL/ULC APPLICATIONS & METAL JAMB	INSTRUCTIONS ADDITIONNELLES POUR APPLICATIONS UL/ULC ET CHAMBRANLE MÉTALLIQUES	INSTRUCCIONES ADICIONALES PARA APLICACIONES UL/ULC Y MARCOS DE METAL
-----------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------

FOR DEADBOLTS	POUR PÉNE DORMANTS	PARA CERROJOS
<i>For UL/ULC application ONLY, follow sequence 1 — 4.</i>	<i>Pour les applications UL/ULC SEULEMENT, observer la séquence 1 — 4.</i>	<i>Para aplicaciones UL/ULC SOLAMENTE, siga la séquence 1 — 4.</i>
<div data-bbox="133 430 920 706"> </div> <hr/> <div data-bbox="106 771 936 1096"> <p data-bbox="170 941 383 974">Break away end tabs. <i>Briser les pattes d'extrémité.</i> <i>Desprenda las orillas.</i></p> <p data-bbox="675 771 936 868">(Optional) STRIKE BOX (En Option) BOÎTIER (Opcional) CAJA DEL RECIBIDOR</p> <p data-bbox="462 998 739 1096">STRIKE (For metal jamb) GÂCHE (Pour chambranle métallique) RECIBIDOR (Para marco de metal)</p> </div>		

FOR KNOBS & LEVERS	POUR BOUTONS ET LEVIERS	PARA PERILLAS Y MANIJAS
<i>For UL/ULC application ONLY, install UL/ULC strike and strike box.</i>	<i>Pour les applications UL/ULC SEULEMENT, installer UL/ULC gâche et boîtier de gâche.</i>	<i>Para aplicaciones UL/ULC SOLAMENTE, instale recibidor y caja del recibidor.</i>
<div data-bbox="122 1380 861 1550"> <p data-bbox="127 1445 383 1534">(Optional) STRIKE BOX (En Option) BOÎTIER (Opcional) CAJO DEL RECIBIDOR</p> <p data-bbox="579 1380 861 1469">STRIKE (For metal jamb) GÂCHE (Pour chambranle métallique) RECIBIDOR (Para marco de metal)</p> </div>		